

INSTRUKSJONER TIL BRUKERE AV MIDLERTIDIGE ELEKTRISKE ANLEGG

1. En kompetent person skal ha tilsyn med anlegget og være ansvarlig for driften. Feil bruk av det elektriske anlegget kan medføre fare for personskade og brann.
2. Sentralen skal plasseres loddrett eller på stativ, og med fritt betjeningsområde foran sentralen.
3. Faste tilkoblinger av kabler og bytte av sikringer skal bare utføres av fagfolk. Ved fast tilkobling av gummikabler skal strekkavlastningens klemflate være utført i isolasjonsmateriale. Ikke-fagfolk skal kun betjene jordfeilbryter, automatsikring og uttak for stikkontakter.
4. Sentralens dører skal være lukket og om nødvendig også låst. Dørene skal bare åpnes ved betjening av sentralen.
5. Elektriske apparater som er koblet til sentralen, skal kobles fra eller gjøres spenningsløse når de ikke er i bruk, for å unngå utilsiktet igangsetting eller anven delse av disse.
6. De elektriske apparatene som brukes, må oppfylle forskriftene og skal enten være utstyrt med ekstra isolasjon eller, i klasse 1-utførelse, med jordet stikkontakt.
7. Kabler må legges slik at de ikke blir skadet. Det gjelder kabler både innenfor og utenfor dørene.
8. Kabler eller apparater med feil skal frakobles og ikke tas i bruk igjen før de defekte delene er skiftet eller reparert.
9. Knivsikring må bare byttes av kompetent personale.

INSTRUCTIONS FOR USERS OF TEMPORARY ELECTRICAL INSTALLATIONS

1. Operation of the installation must be supervised by an authorised person. Incorrect use of the electrical installation could mean risk of personal injury and fire.
2. The distribution unit must be installed vertical or on a stand so that there is free access in front of the unit.
3. Permanent cable connection or replacement of fuses may only be carried out by qualified personnel. Permanently connected rubber-insulated cables must be secured with a restraint that has an insulating gripping surface. Unqualified personnel may only operate earth leakage circuit breakers, miniature circuit breakers and plug sockets.
4. Distribution unit doors must be closed and, where required, also locked. Doors must only be left open when carrying out work on the distribution unit.
5. Electrical equipment that is connected to distribution units must be disconnected or switched off when not in use in order to avoid unintentional starting up or switching on.
6. Electrical equipment that is used must comply with the requirements and must either have additional insulation or comply with class I and have an earthed plug.
7. Cables inside and outside the doors must be routed so as to avoid damaging them.
8. Cables or equipment that are defective must be disconnected and not used until the defective parts have been replaced or repaired.
9. Blade fuses may only be replaced by personnel who have the necessary training.

ARTIKELNR / ARTICLE NO. EB14871			
MÅRKSTRØM/ CURRENT RATING 32	A		
SPÅNNING/ VOLTAGE 400	V		
MEASURING EQUIPMENT			
CURR- TRAFO- SPACE	ENERGY- METER- SPACE		
FAST ANSLUTNING/ FIXED CONNECTIONS			
<125A	>125A		
CEE-OUTLETS 3-POLE			
16A	32A	63A	125A
SCHUKO OUTLETS			
16A			
6			
CEE-OUTLETS 4-POLE			
16A	32A	63A	125A
CEE-OUTLETS 5-POLE/400V			
16A	32A	63A	125A
1	2		
JFB/RCD/RCBO			
0,01A	0,03A	0,1A	
6			
JFB/RCD/RCBO			
0,3A	0,5A	Variable	
VIKT/WEIGHT			
14 kg			








This drawing is property of El-Björn. May not be copied, shown or distributed without our written permission.

U 32CS//612-6 EN 4P



RITAD AV/DRAWN BY CG	DATUM/DATE 200108	NEXT SHEET 2	SHEET 1
SIGN	REVISION/ISSUE A*	RITINGS NR./DRAWING EB14871	

A B C D E F G H J K



ARTIKELNR /
ARTICLE NO.
EB14871

MÄRKSTRÖM /
CURRENT RATING
32 **A**

SPÄNNING /
VOLTAGE
400 **V**

MEASURING
EQUIPMENT
CURR-
TRAFO-
SPACE ENERGY-
METER-
SPACE

FAST ANSLUTNING /
FIXED CONNECTIONS
<125A >125A

CEE-OUTLETS
3-POLE
16A 32A 63A 125A

SCHUKO OUTLETS
16A
6

CEE-OUTLETS
4-POLE
16A 32A 63A 125A

CEE-OUTLETS
5-POLE/400V
16A 32A 63A 125A
1 **2**

JFB/RCD/RCBO
0,01A 0,03A 0,1A
6

JFB/RCD/RCBO
0,3A 0,5A Variable


VIKT/WEIGHT
14 **kg**

This drawing is property of El-Björn. May not be copied, shown or distributed without our written permission.

U 32CS//612-6 EN 4P



RITAD AV/DRAWN BY CG	DATUM/DATE 200108	NEXT SHEET 3	SHEET 2
SIGN	REVISION/ISSUE A*	RITINGS NR./DRAWING EB14871	



L1 4A
L2 4A
L3 4A
N 4A


ARTIKELNR./ ARTICLE NO.		EB14871	
MÄRKSTRÖM/ CURRENT RATING		32	A
SPÄNNING/ VOLTAGE		400	V
MEASURING EQUIPMENT			
CURR- TRAFO- SPACE	ENERGY- METER- SPACE		
FAST ANSLUTNING/ FIXED CONNECTIONS			
<125A	>125A		
CEE-OUTLETS 3-POLE			
16A	32A	63A	125A
SCHUKO OUTLETS			
16A			
6			
CEE-OUTLETS 4-POLE			
16A	32A	63A	125A
CEE-OUTLETS 5-POLE/400V			
1	2		
JFB/RCD/RCBO			
0,01A	0,03A	0,1A	
6			
JFB/RCD/RCBO			
0,3A	0,5A	Variable	
VIKT/WEIGHT			
14			kg

This drawing is property of El-Björn. May not be copied, shown or distributed without our written permission.

U 32CS//612-6 EN 4P



RITAD AV/DRAWN BY	DATUM/DATE	NEXT SHEET	SHEET
CG	200108	4	3
SIGN	REVISION/ISSUE	RITINGS NR./DRAWING	
	A*	EB14871	



ARTIKELNR./ ARTICLE NO. EB14871	
MÄRKSTRÖM/ CURRENT RATING 32	A
SPÄNNING/ VOLTAGE 400	V
MEASURING EQUIPMENT	
CURR- TRAFO- SPACE	ENERGY- METER- SPACE
FAST ANSLUTNING/ FIXED CONNECTIONS	
<125A	>125A
CEE-OUTLETS 3-POLE	
16A	32A 63A 125A
SCHUKO OUTLETS	
16A	
6	
CEE-OUTLETS 4-POLE	
16A	32A 63A 125A
1	2
CEE-OUTLETS 5-POLE/400V	
16A	32A 63A 125A
JFB/RCD/RCBO	
0,01A	0,03A 0,1A
6	
JFB/RCD/RCBO	
0,3A	0,5A Variable
VIKT/WEIGHT	
14 kg	
RITAD AV/DRAWN BY CG	DATUM/DATE 200108
SIGN	REVISION/ISSUE A*
NEXT SHEET 5	SHEET 4
RITINGS NR./DRAWING EB14871	

This drawing is property of El-Björn. May not be copied, shown or distributed without our written permission.

U 32CS//612-6 EN 4P



RITAD AV/DRAWN BY CG	DATUM/DATE 200108	NEXT SHEET 5	SHEET 4
SIGN	REVISION/ISSUE A*	RITINGS NR./DRAWING EB14871	

A	B	C	D	E	F	G	H	J	K
PC.	Position	Description	Type	Manufacturer	Data	Article No.	E-number(SE)		ARTIKELNR / ARTICLE NO. EB14871
1	-	Skåp	Kapsling CS U	El-Björn AB	920x570x310mm	K10188			MÄRKSTRÖM/ CURRENT RATING 32 A
1		Beröringsskydd	S	El-Björn AB		K10000			SPÄNNING/ VOLTAGE 400 V
1		Tak	S	El-Björn AB		K10195			MEASURING EQUIPMENT CURR- TRAFO- SPACE ENERGY- METER- SPACE
1		Uttagsplåt	U S	El-Björn AB		K10006			FAST ANSLUTNING/ FIXED CONNECTIONS <125A >125A
1		Täckplåt	3 Schuko	El-Björn AB	50x190, Vit	233116			CEE-OUTLETS 3-POLE 16A 32A 63A 125A
1		Täckplåt	VE	El-Björn AB	72x72, Vit	75091			SCHUKO OUTLETS 16A 6
3	F01-F03	RCBO	PKPM2-16/2/C/003-A	Eaton	10kA, 2P, C 16A, 30	108111	2162432		CEE-OUTLETS 4-POLE 16A 32A 63A 125A
1	F04	RCBO	mRB6-16/3N/C/003-A	Eaton	6kA, 3P+N, C 16A, 3	120660			CEE-OUTLETS 5-POLE/400V 16A 32A 63A 125A 1 2
2	JF05, JF06	RCD	PFIM-40/4/003-A-SVP	Eaton	40A, 30mA, 4P, A	110781	2162237		JFB/RCD/RCBO 0,01A 0,03A 0,1A 6
1	X00	Intag	432BU6	ABB	32A, 400V, IP44	2CMA193451R1000	2417347		JFB/RCD/RCBO 0,3A 0,5A Variable
6	X01-X03	Schukouttag	Typ F	Mennekes	230V, 16A, IP54	11020EB			VIKT/WEIGHT 14 kg
1	X04	Uttag	416RU6	ABB	16A, 400V, IP44	2CMA192642R1000	2416633		RITAD AV/DRAWN BY CG
2	X05, X06	Uttag	432RU6	ABB	32A, 400V, IP44	2CMA192658R1000	2416660		DATUM/DATE 200108
									NEXT SHEET 5
									REVISION/ISSUE A*
									RTINGS NR./DRAWING EB14871

This drawing is property of El-Björn. May not be copied, shown or distributed without our written permission.

U 32CS//612-6 EN 4P



RITAD AV/DRAWN BY CG	DATUM/DATE 200108	NEXT SHEET 5
SIGN	REVISION/ISSUE A*	RTINGS NR./DRAWING EB14871